

# **EXPERT 2K-FA**

# 2KW SOLID STATE FULLY AUTOMATIC LINEAR AMPLIFIER

# **USER'S MANUAL**





# Index

IMPORTANT4			
PRECA	AUTIONS	4	
UNPAC	CKING	7	
1.	PANEL DESCRIPTION	8	
1.1	Front Panel		
1.2	Rear Panel		
2.	GENERAL INFORMATION		
2.1	Power supply		
2.2	Input / Output		
2.2	ALC / RELAY / CAT		
3.	INTERCONNECTION WITH THE TRANSCEIVER	10	
4.	USE OF THE LINEAR AMPLIFIER		
4.1	SO2R (Single Operator Two Radio )BAND-PASS FILTERS SET "SPE BPF1"	14	
4.2	BAND-PASS FILTERS SET "SPE BPF1"	15	
4.3	QSK (FULL BREAK-IN) OPERATIONREMOTABLE TUNER, UNIT "SPE RAT1"	17	
4.4	REMOTABLE TUNER, UNIT "SPE RAT1"	17	
4.5	TUNEABLE ANTENNA CONTROL	17	
4.6	SETTING UP A SINGLE ANTENNA FOR RECEPTION	19	
5.	EXTERNAL GROUND CONNECTION	20	
6.	ANTENNA	21	
7.	POWER SUPPLY (PSU)	22	
8.	TUNER (ATU)		
9.	PROTECTIONS / ALARMS		
10.	PROGRAMMING		
10.1			
11.	INITIAL OPERATION OF THE AMPLIFIER		
11.1			
	Operating		
	Setting Drive Levels		
12.	CONNECTIONS		
12.1			
12.2			
12.3			
	CAT CI–V Interface		
12.4			
	CAT RS232 Interface		
	CAT 5V TTL Interface		
12.5	5 YAESU	36	
	CAT RS232 Interface		
	CAT 5V TTL Interface	36	
	BAND DATA Interface		
12.6	TEN - TEC, FlexRadio, ELECRAFT	37	
	CAT RS232 Interface		
12.7		39	
13.	OTHER CONNECTIONS		
13.1			
13.2			
13.3		₁0 ⊿1	
13.4			
13.4			
13.0	RS232 port Remoting use		
1.1	RS232 port Remoting use TRANSCEIVER CONTROLLED WITH A PC	43	
14.			
14.1			
14.2	2 RS232 INTERFACE	4/	



14.3	5V TTL KENWOOD INTERFACE	47
14.4	5V TTL YAESU INTERFACE	48
15.	USB / RS 232 PORTS USAGE	48
15.1	REMOTE CONTROL	49
15.2	DOWNLOAD	49
16.	MAINTENANCE	50
17.	CHARACTERISTICS / SPECIFICATIONS	51
18.	DIAGNOSTICS	53
19.	TABLE	54
20.	APPENDIX 1 "TERM 2K SHORT GUIDE"	55
20.1	SW installation	55
20.2	Term_2K_USB.exe usage	60
20.3	Term_2K_232.exe usage	69
20.4	Firmware update	72
21.	GENERAL RESTORE	
22.	WARRANTY TERMS	75
<b>REPAIR F</b>	FORM	77



Congratulations for choosing the SPE EXPERT 2K-FA solid state linear amplifier: It is small and powerful, it covers all the amateurs bands from 1.8 to 54 MHz WARC included, completely automatically and remotable.

All operating conditions (frequency, antenna, tuner etc.) are controlled from your transceiver. The operator has only to move the frequency tuning knob on the transceiver.

It is possible to connect it to every type of device, it is extremely user-friendly and offers a product which is best-in-class.

# **IMPORTANT**

Read this instruction manual carefully before attempting to operate the linear amplifier.

The warranty will be invalidated in the case of non-observance of these instructions.

Keep this manual. It contains important safety and operating instructions for the SPE EXPERT 2K-FA.

This manual may be subject to changes and updates therefore please refer always to the updated version available on the website www.linear-amplifier.com. If in doubt, refer to the English language version.

# **PRECAUTIONS**

**Explicit definitions** 

WORD	DEFINITION
<b>⚠</b> WARNING!	Risk of danger of fire or electric shock to persons.  Possible damage to the amplifier.
NOTE:	Serious problems if not observed. Danger of fire or electric shock for the operator, or damage to the equipment.



# WARNING!

HIGH VOLTAGE! DO NOT disconnect an antenna from the amplifier during transmission; electric shock or fire is possible.



# 🔼 WARNING!

DO NOT modify the internal wiring of the amplifier. Any modifications will invalidate the warranty, and may reduce the performance of the linear amplifier or damage it.



# 🔼 WARNING!

**Before** using the linear amplifier, compare the value of voltage of the local mains supply network with the value required by the amplifier.



# 🔼 WARNING!

**DO NOT** turn ON the linear amplifier unless it has been properly grounded through the green/yellow conductor of the mains cord. Your dealer will already have provided the



correct mains plug for your local electricity network, with the earth pin connected to that conductor. Do not disconnect this under any circumstances, or there is a risk of severe or fatal electric shock.



# **!** WARNING!

DO NOT use an extension cord with the AC power cable, as if it is not correctly rated there is a risk of fire or electric shock. WARNING!

**DO NOT** allow metallic objects or wires to enter inside the amplifier.



# 🔼 WARNING!

**DO NOT** obstruct the entries for cooling air at both the sides of the amplifier. Ensure that no object impedes the correct operation of the fans.



# WARNING!

**DO NOT** expose the linear amplifier to rain, snow or any liquids.



# WARNING!

**DO NOT** install the linear amplifier in a place without good ventilation. This could limit heat dissipation and the amplifier could be damaged.



# **!** WARNING!

**DO NOT** touch the amplifier with damp or wet hands. There is danger of electric shock. Avoid opening it before you have disconnected it from the mains supply, then wait at least 2 minutes for electrolytic capacitors to complete their discharge.

To clean the amplifier DO NOT use chemical agents like alcohol or benzene because the plastic surfaces could be damaged.

AVOID using the amplifier in areas with temperatures below -10° C (+14°F) or above +40°C (+104°F).

AVOID using the linear amplifier in locations that are very dusty, damp or in direct sunlight.

AVOID placing the linear amplifier against walls, the circulation of the air would be obstructed and the noise of the fans would be reflected toward the operator.

AVOID permitting children to play with the amplifier.

If you do not use the linear amplifier for long time, set the back main switch [I/O] to the OFF position [O].



# Information for Users on Collection and Disposal of Old Equipment and used Batteries.



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation.

This amplifier should only be operated by persons who have an appropriate radio transmitting license.

You should observe your license conditions while using it in accordance with national legislation.



# **UNPACKING**

Remove the packing and carefully check the contents.

If you find any damage or if there are any parts missing, contact your retailer immediately.

Keep the shipping cartons for future transportation if required.

# Accessories included in the carton

- a) Transport carry bag.
- b) 2 cables with RCA (phono) connectors for ALC, RELAY links. 1 USB standard cable.
- c) 3 connectors DB-15, n. 1 connector DB-9
- d) User manual.
- f) Spare fuses:


- g) Spare air filter.
- h) Certificate of compliance and warranty form.





#### PANEL DESCRIPTION 1.


#### 1.1 **Front Panel**



- 1) ON
- 2) OFF
- switches between display pages. 3) DISPLAY
- switches output power from "MAX / MID / LOW". 4) POWER
- switches between Standby / Operate. 5) OPERATE
- 6) SET used to program the amplifier.
- 7) ▼▶ used to program the amplifier. used to program the amplifier. 8) ◀▲
- 9) INPUT selects one of the two inputs of the amplifier.
- 10) **◀BAND** switches bands manually (downward in frequency).
- 11) BAND▶ switches bands manually (upward in frequency).
- switches the antennas for every single band 12) ANT
- 13) CAT shows the current CAT interface setting.
- 14) TUNE: starts the automatic tuning process.
- 15) **◀**C used for manual tuning.
- used for manual tuning. 16) C▶
- used for manual tuning. 17) **◀**L
- 18) L▶ used for manual tuning.
- 19) TX red led, illuminates during transmission.
- yellow led, illuminates when the amplifier is in "Operate" state. 20) OP
- 21) ON green led, illuminates when the amplifier is "ON".
- 22) SET green led, illuminates during programming.
- 23) TUNE yellow led, illuminates during tuning.
- red led, illuminates when there is an alarm. 24) ALL
- 25) DISPLAY
- 26) AIRFLOW GRID



## 1.2 Rear Panel



1) ANT connectors for six possible antennas.

2) SO2R connector for SO2R operations

3) INPUT connectors to connect two exciters.

4) FANS

5) IN 1 ALC, RELAY, CAT connectors for exciter 1.
6) IN 2 ALC, RELAY, CAT connectors for exciter 2.

7) PORT "PORT". 8) PORT "USB". 9) PORT "AUX".

10) ON main switch.11) FUSE 1 PA unit, 20A.

12) FUSE 2 electronic unit 0,5A.13) AC mains power cable.14) GND ground connector.



# 2. GENERAL INFORMATION

(Read the specific chapters for more details).

# 2.1 Power supply

The linear uses a switching power supply with a continuous input between 190 and 255 Vac

The main switch [I/O] is located on the rear panel. In the [O] position all the internal circuitry is powered off, in the [I] position (red led ON) it is possible to turn ON or turn OFF the linear amplifier in one of the following ways:

- a) Using the [ON]/[ OFF] keys on the front panel.
- b) Applying / removing 9 -15 Vdc. on pin (8) of the CAT connector.
- c) Using the USB port and the management software. It is possible to download this software from the website www.linear-amplifier.com

Note: when turned ON, almost all transceivers output 13.8 Vdc. With this voltage, the linear amplifier can be turned automatically ON / OFF at the same time as the transceiver.

# 2.2 Input / Output

The linear amplifier has two inputs (INPUT 1, INPUT 2) to which it is possible to connect two transceivers of any brand or type.

These inputs are selected with the [INPUT] key or automatically with the PTT of each transceiver.

It can manage up to six antennas (ANT 1, ANT 2, ANT 3, ANT 4, ANT 5, ANT 6).

The amplifier selects antennas automatically when they have been programmed.

The SO2R functionality is implemented using its own connector.

#### 2.3 ALC / RELAY / CAT

There are two transceiver inputs (IN 1, IN 2), to allow two different transceivers to be connected at the same time.

ALC is a voltage (0, -11 Vdc.) generated by the amplifier. It is used to control the output power of the transceiver (max. in STANDBY", the required in "OPERATE").

In this way the power from the exciter may be automatically regulated.

If the ALC port is not connected, it is necessary to manually regulate the drive power from the transceiver.

This link is highly recommended.

RELAY **This essential link** allows the amplifier to be put in the transmit state. To do that it is necessary that the inner pin of the phono connector is connected to signal ground. This is normally done at the transceiver with either a "close-on-ground" relay, or with a switching transistor. It is important that the voltages at that terminal do not exceed 12 Vdc. On the transceiver this link is often called SEND or TX GND. Refer to your transceiver manual for more details.



# CAT This link is highly recommended.

Thanks to this link the linear amplifier will detect, while in receive mode, the operating frequency of the transceiver and then automatically control changes of band, antenna and automatic antenna tuner. Most modern transceivers have CAT control. In old models often, analog or digital information are sent for changing band. The SPE Expert 2K-FA, thanks to an efficient frequency counter, constantly controls and verifies data coming from the transceiver. Automatic management of bands, antennas and tuner can be done in the following way:

- a) In all recent transceivers through CAT connection (HIGHLY RECOMMENDED).
- b) In the YAESU models not listed, or without CAT, through "BAND DATA".
- c) Configurations a) and b) are recommended. In older radios which do not have CAT or BAND DATA through the internal frequency counter.

Note: in case c) the CAT link with the transceiver is not needed because the frequency is detected from the transmitted signal.


FOR THIS REASON, BECAUSE OF THE HIGH POWER IN USE, IN ORDER TO NOT DAMAGE THE LINEAR, WE STRONGLY RECOMMEND YOU CHANGE BAND WITH THE LINEAR IN STANDBY MODE.

USE THE CONDITION c) ONLY IF CONDITIONS a) OR b) ARE IMPRATICABLE.

Note: in some transceivers the "RELAY" and "CAT" signals are activated by menu selection: refer in this case to their user's manuals..



# 3. INTERCONNECTION WITH THE TRANSCEIVER



The diagram shows the connections with one transceiver only. To connect the second transceiver repeat the same connections using the port "IN 2".

For the ALC, RELAY connections, use the shielded cable (supplied) with phono RCA connectors.

For the CAT connection, the cable must be made for the transceiver to be connected. This cable may also be made to include ALC, RELAY ON / OFF (read the "CAT CONNECTIONS" chapter of this manual).


For all other information about connecting a transceiver, please refer to its manual.

Note: Do not use the RELAY and ALC phono connections if they have been implemented in the DB15 "CAT" connectors.



# 4. USE OF THE LINEAR AMPLIFIER

#### Block diagram.



The position of the contacts, as shown in the diagram, is the situation of the linear amplifier in OFF state.

The linear amplifier can be used in the following ways:

1) OFF Only two direct connections are actuated:

between INPUT 1 and ANT 1 between INPUT 2 and SO2R

2) STANDBY All the functions are activated (band change, antenna change, tuner

control) but the transmission is from the transceiver only.

3) OPERATE All the functions are activated and the transmission is using the


linear amplifier.

Note: regulation of the exciter's power is automatic through the ALC connection. With the ALC connected, the amplifier input power in OPERATE mode is reduced to the correct level to drive the amplifier. In standby, the exciter will give the output power as set by its POWER OUTPUT control. Without the connection, you have to manually regulate the exciter power to drive the amplifier correctly in order to avoid damaging the amplifier.

**EXPERT 2K-FA** 



#### 4.1 SO2R (Single Operator Two Radio )



This kind of operation is used during a contest in order to acquire, as quickly as possible, a new multiplier.

The following connections are needed (see the diagram):

- 1. **INPUT 1** connected to the first transceiver (RTX1).
- connected to the second transceiver (RTX2). 2. INPUT 2
- 3 ANT 1/2/3/4/5/6 connected to the available antennas set.
- 4. SO2R connected to a multi-band antenna.

The operating mode could be the following:

If you are operating using RTX1 on a given band (e.g. 20 m), the correct antenna (ANT 1/2/3/4/5/6 is automatically selected while RTX2 is connected to the multi-band antenna in RX mode on another band.


If, when operating on 20 m, a multiplier of interest is heard on RTX2 (e.g. 40 m), the only action needed is to push the PTT2 in order to connect RTX2 to the 40 m antenna, while RTX1 will be switched to the multiband antenna in order to receive the 20 m band.

In place of the multiband antenna one of the antennas ANT 1/2/3/4/5/6 can be used, in such a case all of them must be mono band to avoid the danger of using the same antenna for RTX1 and RTX2...

A careful design is needed to avoid such a danger which could be devastating for the

This possibility is available with the optional external unit "SPE SO2R1" according to the following diagram.





The unit is controlled and powered from the AUX port.

Note: the isolation between the transmitting antenna and the receiving antenna must be very high and, therefore, very well planned. Locating the antennas at some distance from each other, and using appropriate band-pass filters will help to achieve this. However, SPE is not responsible for any damage caused to equipment.


#### 4.2 BAND-PASS FILTERS SET "SPE BPF1"

To increase the isolation between the transmitting and the receiving antenna SPE offers the optional unit "SPE BPF1" which must be placed between RTX1 / RTX2 and linear. The unit is controlled and powered from the AUX port. (Contact factory or your distributor for availability).

The unit automatically enables the following features:

a) DXpetition, Contest Multi / Multi. In this case the amplifier is connected to a single transceiver (INPUT 1 / 2). "SPE BPF1 automatically selects the filter on the band to be used in the input where the transceiver is connected, while the other unrelated input is unused.






# 2) Contest SO2R.

In this case the amplifier is connected to two transceivers.

"SPE BPF1" automatically selects the right filters and the right inputs as well.



These features can be possible also with the simultaneous use of the unit "SPE SO2R1, (use the AUX port with a Y cable).

To ensure the perfect functionality of these options, the use of the CATs is recommended.



# 4.3 QSK (FULL BREAK-IN) OPERATION

The Expert 2K-FA allows also QSK (FULL BREAK-IN) operation. Thanks to the perfect control carried out on RX / TX switching relays, any possibility of "hot switching" is avoided.

This feature is compatible with all modern transceivers, in fact the minimum delay required before transmission is only 6.5 msec. (check the manual of the transceiver). In the case (very remote) of minor delay, you can use the link TX - INH (see "CAT" paragraph) or, upon purchase, ask for optional installation of "vacuum relays" (Kilovac HC1 12 Vdc.)

# 4.4 REMOTABLE TUNER, UNIT "SPE RAT1"

The Expert 2K-FA has inside an automatic tuner (ATU) system that allows the selection of 6 different antennas and their automatic tuning (see "TUNER" paragraph).

The "SPE RAT1" allows to remote such ATU bringing to a more convenient location (roof, towers etc..), using a single coaxial cable, no other cable is required.

The length depends only on RF cable attenuation.

You get the following benefits:

- A single cable between the amplifier and antennas.
- Cable always perfectly matched, and hence lower losses.
- ATU closer to the antenna.
- Drastic reduction in the number of cables that stem from the shack, and hence money saved.

The "SPE RAT1" is provided in a water proof container, the procedure of installation is very simple:

- Remove the ATU unit from the linear.
- Install in its place the new unit included in the option.
- Install the ATU in the water proof container.
- Connect, with a coaxial cable, the unit replaced with the "SPE RAT1".

Following these simple steps (explained in detail) it is possible to have remotely the same features as if the ATU is still inside the linear.

(Contact factory or your distributor for availability)

#### 4.5 TUNEABLE ANTENNA CONTROL

The use of tuneable antennas (SteppIR, Ultrabeam) is becoming popular. These antennas vary the physical dimensions of the elements in accordance with the operating frequency to guarantee always a perfect resonance.

The Expert 2K-FA, through the dedicated connector "PORT" connected to the antenna controller, allows their automatic control following the tuning knob.

This dedicated link allows the following advantages:

- Simplification of wiring, the difficulty of adding an additional wiring to CAT input is removed.
- Compatibility with all types of CAT, the Expert 2K-FA converts the CAT protocol, so two different transceivers (CATs) can be used simultaneously with the same controller.
- Thanks to the frequency counter inside the linear, the antenna can be controlled also without the use of CAT.




All of the automatic features of the linear are retained even in the most complex configurations, antennas of all kinds can be connected to the connectors "ANT", the Expert 2K-FA will choose the antennas according to the set-up and will manage them according to their characteristics.

The CAT is recommended, if the transceiver does not have the CAT or if has only the "Band Data", the Expert 2K-FA will continue to drive the antenna with the frequency measured by the counter (data collected after the first transmission).

Up to 6 tuneable antennas can be controlled through their own controller.


The simplest configuration is a single tuneable antenna according to the following diagram:



The link is unique for any position (ANT 1,2,3,4,5,6) you want use.



If you have several tuneable antennas (up to 6) and their controllers, the optional unit "SPE CBU1" is needed according to the following diagram:



In this case you need to connect the unit control box outputs 1,2,3,4,5,6 in accordance respectively with the antennas ANT 1,2,3,4,5,6.

For the selection of antennas, refer to the "ANT TUN" in the menu.

The Protocol used is "Kenwood", the communication speed is "settable,"

#### 4.6 SETTING UP A SINGLE ANTENNA FOR RECEPTION

In some cases it may be appropriate to transmit with an antenna and receive with a more appropriate one.

A unique feature allows the Expert 2K-FA to set a receiving antenna and to provide an its automatic switching after transmission.

For the selection of this antenna refer to the menu item "RX ANT".

The antenna number selected will appear close to an "r" (e.g. 3r).

Because, with linear OFF the INPUT1 is directly connected to ANT1, the selection of ANT1 is not permitted to avoid some possible danger to the transceiver if only a receiving antenna (e.g. beverage) is connected.



#### 5. **EXTERNAL GROUND CONNECTION**

WARNING! Before connecting an external ground as described below, check with a qualified electrician that your national wiring codes permit such a connection.

To reduce TVI, BCI and other RF problems it is sometimes helpful to connect the amplifier to a good RF ground.

The inductance of such a connection has to be low, so the connection to ground should be as short and direct as possible. Large-section copper conductors should be used for this purpose. Terminating the earth connection with a small metal plate is suggested.

The best solution is to have a ground stake, driven into the ground, and used only for the radio station.

Often good results can be achieved using correct earthing clamps, connected to the main water supply pipe (attention, most water pipes are now in plastic).

DO NOT use central heating pipework.

AVOID the electric circuit ground of the building (to be used for 50/60 Hz safety only).



**WARNING!** DO NOT connect to gas pipes because there is danger of explosion!!



# 6. ANTENNA

Because this is a high-power amplifier, it is necessary to use correctly-rated antennas, connectors and feed line cables.

Take special care with antennas using baluns, traps, because balun / trap warming can occur during periods of high-power transmission and a high SWR can result.

This dangerous situation is often not perceived by the operator because normally a measure of SWR is made when balun and antenna are not under stress.

A unique feature of this linear is that, it not only measures the SWR after the matching, but also the SWR of the system antenna / cable, this allows to always evaluate your antenna system despite the matching and the power applied.

Always use antennas with SWR less than 2:1 even if the tuner is able to overcome some mismatches greater than 3:1.

With the tuner the PA is matched, but with a high VSWR, the cable is mismatched and there can be consequent loss of power, heating and high voltages present.

Always operate with the best possible matching because, despite the amplifier's protection against high SWR, continuous use into a mismatched load (a bit lower than the protection threshold) may lead to damage.

It is suggested that suitable static protection be given to antenna feeder cables.

The software allows you to select up to three antennas for the same band.



# 7. POWER SUPPLY (PSU)

The power supply of the SPE Expert 2K-FA, unique in its category, is switching with a PFC (Power Factor Correction) that allows a drastic reduction of the harmonic components in the mains in accordance with IEC555-2, it consists of two separate elements.

The first powers all the electronic circuits for command and control.


The second powers only the PA, its output voltages are 48 Vdc (MAX Pout), 35 VDC (MID Pout), and 30 Vdc (LOW Pout).

This design was adopted as it provides maximum efficiency and therefore less heat to dissipate.

The power supply meets the followings rules: UL60950-1, TUV EN60950-1, EN55022, EN61000-3-2,-3, EN61000-4-2,3,4,5,6,8,11; ENV50204, EN5502.

Since the amplifier is sold all over the world, the power cord does not come with any mains plug. Normally your SPE distributor will fit the plug appropriate to your domestic supply network prior to purchase. Should it be necessary to rewire the plug due to relocation in a different country, please seek advice from a qualified electrician.

To apply the plug (20 A minimum) proceed according with the following fig.



You should observe all precautions in accordance with national legislation.

The amplifier is supplied to a power supply that automatically adapts between 190 and 255 Vac. 47-63 Hz.

In case of "FATAL" alarm the power supply is blocked, to restore the linear set OFF for about 30 seconds. via the rear switch, then back ON.

In order to reduce the noise, in "Operate" the speed of the fans is increased only during the transmission time, while in "standby" they are stopped.



# 8. TUNER (ATU)

The amplifier has an automatic tuner that handles load mismatches up to 3:1 VSWR (2.5:1 for 6 m).

The amplifier contains a look-up table with all the permitted bands.

For tuner management, antenna data and other working data are stored.

Every band has a sub-band set, and for each of those, data related to the antenna and auto-ATU tuning is stored.

The CAT and the frequency counter detect the operating frequency and the correct sub-band. Thanks to the stored data, the tuner and the antenna are automatically set correctly.

For every input there is a different table. If two exciters are connected at the same time, each exciter can have different configurations.

It is possible to use the two different tables when the amplifier operates at two different locations. In fact it is possible to use the INPUT 1 at one and INPUT 2 on the other.

In this way a repeated reprogramming is not needed.

Furthermore, table driven management is useful to inhibit operation of the amplifier, for instance when an antenna for a particular band is not available.

All auto-tuner functions remain, on standby, while using the transceiver only.

Setting of the match data to write to the tables is performed automatically by pressing the [TUNE] key. The system will then find the correct match for minimum SWR.

To achieve a better match than that achieved with the automatic tune routine (most unlikely) it is possible to set the tuning manually by using the keys  $[\blacktriangleleft C]$ ,  $[C\blacktriangleright]$ ,  $[\blacktriangle L]$ ,  $[L\blacktriangleright]$ .

When manual tuning has been performed, it is possible to read the tuning value, the working frequency and the associated sub-band on the appropriate screen page.

Both the types of tuning are always implemented in "STANDBY" state.

Before beginning the matching process, the tuner measures the SWR of the system cable / antenna. if it is greater than 3.5:1, the procedure does not begin and an alarm is given.

It is possible to bypass the tuner with a specific command, in order to use an external tuner.

NEVER USE THE INTERNAL TUNER WITH AN EXTERNAL ONE, it could seriously damage the linear.

IF YOU WANT USE AN EXTERNAL TUNER, DISABLE THE INTERNAL ONE.

The internal tuner may be disabled:

- Totally.
- For single band.
- For single band only with a specific antenna.

It 's always automatically disabled:

- With the only receiving antenna set
- With tuneable antenna set.

Note: the tuner, like all analog circuits, introduces a loss (0.8 dB max.) that may vary with tuning conditions. The power meter of the amplifier does not show this loss as the power is measured at the tuner input where the load resistance is always constant (50 ohm).





Note: ATTENTION: When the amplifier is either in "STANDBY" or "OPERATE" mode,

always disable the automatic tuner in your transceiver.

Note: ATTENTION: As two different tables are used for INPUT1 and INPUT2, it is necessary

to program separate matching, for the same antenna, depending on the used input. Ignoring this caution could make the amplifier work for a long period with a high SWR and this practice could seriously damage the amplifier even if the protection level is a

bit lower than the threshold.



# 9. PROTECTIONS / ALARMS

The SPE EXPERT 2K-FA has a sophisticated protection system that constantly monitors and controls the amplifier's most important parameters.

These parameters are:

Temperature of the heatsink; max. / min. voltage on the PA; max. PA current; SWR; reflected power; max voltage RF on the tuner; input power; power combiner balance.

The protection system is effected in two different ways:

- 1) Through hardware circuits to guarantee minimum intervention time.
- 2) Through software, with one of the two CPU's, to guarantee the maximum precision.

The two results are always compared, every difference produces a protection trip and consequent alarm.

There are three types of protections/alarms:

a)	SIMPLE	This is the most common case. An acoustic warning been
		sounds, but no operator intervention is required, as the control
		system automatically restores the correct operating conditions.

b) SERIOUS When automatic system recovery is not possible (e.g. the temperature climbs over the limits due to obstruction of the fans, SWR is too high, etc.). In this case the amplifier switches into standby state and the alarm is stored. Normally transmission can continue with the exciter only.

c) FATAL If the amplifier is in the b) situation but one CPU is faulty or it isn't able to operate or some fault appears in the power supply, the amplifier is turned OFF with no other warning. To restart the amplifier, the main switch in the rear panel has to be set first to [O], and then to the [I] position.

Note: it is possible to read the alarm history in the standby mode using [SET] and then [ALARMS LOG] keys, to reset the alarm file press [TUNE] and [OPERATE] keys together.
For further details, please consult the next paragraphs

Note: if the acoustic alarm is very frequent during transmission, the possible causes should be investigated.

Note: before the temperature limits are reached (76°C), the output power will change from MAX to MID automatically and then possibly from MID to LOW, so that transmission with the amplifier may continue with reduced power.

If the temperature, in LOW, is allowed to rise further, a "SERIOUS" alarm will eventually be activated and the linear switched in STBY.

Note: during a SERIOUS alarm, there is an acoustic alarm for 10 sec. Pressing the [DISPLAY] key, the system changes to 'STANDBY' state immediately.

Note: ATTENTION :when a "FATAL" alarm occurs, immediately contact your reseller.



# 10. PROGRAMMING

The three keys: [SET], [◀▲] and [▼▶], are underlined with an orange line and permit programming the amplifier. They can be used in the following way:

[SET] Use it to open the menu page, to validate the choices and to exit from the menu page.

 $[\blacktriangleleft \blacktriangle]$ ,  $[\blacktriangledown \blacktriangleright]$  Use these to select the options.

A green led illuminates during the programming process.

Programming the system is very easy. You will find your programming choices confirmed by the items shown at the lower part of the display.

Note: programming is only possible in 'STANDBY' mode.

Note: programming changes take effect only after exiting from the menu page (the


green led turns off).

Pressing the [DISPLAY] key will come back immediately to STANDBY without

any programming effect.

# 10.1 Ways to operate

Pressing the [SET] key opens the menu page. On the display there are the following options:



a) ANTENNA An appropriate antenna may be assigned to each band selecting the (ANT 1, ANT 2, ANT 3, ANT 4, ANT 5, ANT 6) connector. If you don't have an antenna for a particular band, input "N".

This setup allows you to preset up to 3 antennas for the same band.



The selected antennas can be switched using the [ANT] key while working either in "OPERATE" or in "STANDBY" mode.


If you want, for a certain band and for a certain antenna, bypass the tuner, just press the [TUNE] key will see a "b" next to the box. To remove the bypass re-press [Tune].

b) CAT

000

Allows you to program the amplifier to accept control commands from specific transceiver types.

You may need to refer to your transceiver user manual to ensure that it is correctly programmed to handle such a link.



Select the brand or function, for the proper link see "CAT CONNECTIONS" on this manual.

-	SPE	No further programming is necessary, everything is aiready
		programmed for the SPE transceivers.
-	ICOM	Set the "CI-V" protocol, you also need to choose the baud
		rate which is usually 9600.
-	KENWOOD	You have to choose the baud rate (almost always 9600).

 YAESU If you use the CAT connection (read the "CAT CONNECTIONS" chapter of this manual), sele

CONNECTIONS" chapter of this manual), select the model of the transceiver and than select the baud rate (almost always 4800). If the model isn't in the list, select "Band Data" (read the "CAT CONNECTIONS" chapter of this manual). For new models not listed, select FT 2000/9000 or even

"Kenwood".

- TEN-TEC Make the CAT connection (read the "CAT CONNECTIONS"

chapter of this manual) and follow the menu instructions.

- FLEX-RADIO Make the CAT connection (read the "CAT CONNECTIONS"

chapter of this manual) and follow the menu instructions.

ELECRAFT Make the CAT connection (read the "CAT CONNECTIONS"

chapter of this manual) and follow the same indications as for

KENWOOD.

- NONE Program when there isn't a link with the Transceiver.

The amplifier frequency counter will then be used.


Note: if using the CAT, check that the baud rate of your transceiver is set to the same value as you program to the amplifier.



c) MANUAL TUNE Allows you to tune the amplifier manually, however achieving a

better setting than that obtained by automatic tuning is very

unlikely.



Set your exciter to transmit a continuous RTTY or CW signal.

Press the  $[\blacktriangleleft L]$ ,  $[L \blacktriangleright]$ ,  $[\blacktriangleleft C]$ ,  $[C \blacktriangleright]$  keys until you obtain the minimum SWR.

The operating frequency and the sub-band are also shown on the Display.

Note: the tuning process has to be repeated for every entry (INPUT1, INPUT 2).

d) DISPLAY Regulates the backlight and the contrast of the display.

e) BEEP All acoustic warnings alarms operate and a beep confirms a On:

keystroke.

Off: When you press a key there is no beep feedback, but for

all warning conditions and alarms, the acoustic warnings

are still functional.

Stby: Sets STANDBY mode at startup. f) START

Oprt: Sets OPERATE mode at startup.

°C: Displays temperature readout expressed in Celsius degrees. g) TEMP

> °F: Displays temperature readout expressed in °Fahrenheit

degrees.

h) ALARMS LOG Shows the most recent 10 "SERIOUS" alarms occurred.

i) TUN ANT Allows you to associate a tuneable antenna to one of 6 ANT

connectors.

A "t" highlights the selected antenna.

Allows you to set a single receiving antenna. j) RX ANT

An "r" highlights the selected antenna.

k) FAN NOISE QUIET MODE: minimizes fans noise of the PSU in Operate which

> then only runs during the transmission mode. Suitable if the 80ms rise time of the PSU will not affect the start of a transmission (e.g.

SSB).

NORMAL MODE: the PSU fans, in Operate, always are running,

albeit more slowly in receiving mode.



The PSU is always ON so that it can't affect the first symbol of a transmission (e.g. CW, RTTY).

# 11. INITIAL OPERATION OF THE AMPLIFIER

Before turning ON the amplifier, read this manual with care.

The following preliminary operations are necessary:

- 1) Be sure that the amplifier is correctly set for the local mains voltage supply.
- 2) Connect the amplifier to the ground circuit
- 3) Connect the antennas.
- 4) Connect the amplifier to the transceiver (read the "CONNECTIONS WITH THE TRANSCEIVER" chapter of this manual)

Operate [I] the main switch on the back panel, and press the [ON] key on the front panel.

Select the INPUT for the transceiver, and always carry out programming with the amplifier in STANDBY. If you change INPUT you have to repeat this programming.

Note: you may have to repeat some programming if you change antenna, transceiver, etc.

Note: ATTENTION the 'RELAY' and 'CAT' signals in some types of transceivers are only turned ON from a transceiver MENU. Refer to the user manual.

Note: ATTENTION, when the amplifier is in the 'STANDBY' and 'OPERATE' modes, always disable the transceiver auto-ATU.

# 11.1 Initial Programming

You must carry out the next steps in the sequence below:

#### a) Set Antenna.

Press [SET] and open the "ANTENNA" menu page.

Assign an appropriate antenna for the band concerned. If you don't have an antenna for a band, input "N".

When all the antennas are programmed, press [SET] to exit and go back to STANDBY.

#### b) Set CAT.

Press [SET] and enter the "CAT" menu page.

Select the transceiver brand and progress with programming according to the type of connection between the amplifier and the transceiver (read the "CAT CONNECTIONS" chapter of this manual).

At the end of programming, exit and go back in STANDBY.

To verify the correctness of programming, press the [CAT] key, and all the data stored will appear on the display.

To verify the correct "CAT" operation, press [SET] and select "MANUAL TUNE", While changing your transceiver VFO, you should see the amplifier frequency display follow.



If set to "None ", transmitting briefly in RTTY or continuous key-down CW, you must read the top left transmitted frequency.

Then return to STANDBY.

In the same way, if "BAND DATA" is connected, check that the amplifier follows band changes at the transceiver.

If it does not, verify that your programming (or your link) has been done correctly.

c) Use of Automatic Tuner

To complete the programming it is necessary to match the antennas to the amplifier by operating "TUNE" (read the "TUNER" chapter of this manual). We recommend you select each band (with available antenna) and then program the tuner for the sub-bands within which you will operate. Refer to the table in section 19 of this manual to select the appropriate sub-bands for your operating preferences.

You are strongly advised to proceed with the utmost accuracy, not just match the current frequency, but all the sub-bands you are likely to use. Matching all the antennas on all bands available you will enjoy all the features of the automatic linear.

#### Proceed as follows:

- 1) Find the central frequency of the sub-band to tune in the table (refer to section 19 of this manual) and set the transceiver to that frequency.
- 2) Set your transceiver to transmit a continuous tone (RTTY or FM).
- 3) Press the [TUNE] key, then the PTT. The procedure for automatic tuning will start (you will hear the ATU relays operate) and then it will stop when SWR is at a minimum. Sometimes it is possible to improve tuning by repeating this step.
- 4) Repeat the previous steps for all bands and sub-bands you want.
- 5) Repeat the previous steps for any other antennas of the same band after having selected it using the [ANT] key.

Note: if the ALC link is not used, it is **very important** to reduce the transceiver power to about 50 Watts during this operation.

#### The initial programming concludes after steps a), b), c).

#### Operating

You need to exercise only a few precautions when using the amplifier thanks its high level of automation.

ALC and CAT links are highly recommended.

If ALC is not used, SPE reminds you that it is better to lose a fraction of dB in transmitted power, by slightly reducing the drive power, than to over-drive the amplifier and have a poor quality transmission.

During transmission check the parameters on the display always, because SPE has selected, designed and adjusted them with care.

SPE recommends (when using the ALC link) that the transceiver should be set to its maximum output power, the ALC will reduce the driving power to the optimum driving level.

To reduce the linear output, if required, it is then necessary only to set the amplifier to "MID" or "LOW" with the [POWER] key.



Of course you may also regulate continuously the amplifier output power by changing the level of drive power from your transceiver (also with the ALC connected). If less output power than 2KW, 1KW or 500 Watts is desired, it is preferable, for best efficiency, to start to reduce drive from "MAX", "MID" or "LOW" power state.

# Setting Drive Levels

- a) SSB: Regulate the "MIC GAIN" of the transceiver until, speaking normally into the microphone, the signal peaks on the display don't quite reach the maximum rated output power. Monitoring the transmission is a good way of checking your settings. If there is however some distortion, decrease the "mic. gain" or decrease the power of the transceiver until a small reduction of the output power of the amplifier is seen.
- b) CW: In key down, you get the maximum output power automatically.
- c) RTTY, Digital modes, SSTV, FM: Because all of these types of transmissions have a very heavy duty cycle, you should not operate in 'MAX' but only in "MID" and "LOW". An appropriate SW ensures this requirement.
- d) AM: This transmission mode radiates a continuous carrier which is 25% of its PEP value (e.g. 400W PEP AM = 100W carrier power). SPE recommends you always operate in 'MID' or "LOW" mode for AM.

  To get an output signal without distortion, proceed as follows: transmit the AM carrier only, with your transceiver "MIC GAIN" set to zero, set the transceiver without exceeding 25% of the maximum carrier output from the amplifier.

  Then, speaking into the microphone normally, set the "MIC GAIN" of the transceiver until the peak output power, on speech peaks, as shown on the amplifier display, is no more than 1 KW or 500W. SPE suggests you monitor your transmission to check that the "MIC GAIN" setting is correct.
- Note: if you choose to set the output power of the amplifier by varying the output power of the transceiver, the ALC connection is not strictly required.

  In this case **you** must be careful not to overdrive the amplifier to avoid distortion and broadening of the channel (with the ALC, adjustment is automatic for maximum linearity and Pout).


  All functionalities remain the same protections included, the only feature that is less is the return to full power to the transceiver when it returns to STANDBY.
- Note: ATTENTION, never stress the amplifier with long periods in key-down transmission, as this can stress the amplifier components. An appropriate SW avoids transmitting a continuous signal in the "MAX" condition for a long time by switching to "MID".
- Note: in SSB use a compressor only when necessary; this strongly reduces the temperature increase.



# 12. CONNECTIONS

# 12.1 CAT Connector

In this diagram the rear panel CAT connector and pin-outs are shown. If you have already used our 1K-FA amplifier you will note the connections are the same.



pin n.	pin name	Description
1	RX 232	Used on KENWOOD and YAESU transceivers for the link with a RS-
9	TX 232	232 connection.
2	/ TX - INH	Open collector normally off, stops transmission when gnd. (on).
10	RX TTL	Used on Icom, KENWOOD and YAESU transceivers for the CAT 5V
3	TX TTL	TTL connection.
11	KEN TTL	Connect to GND if CAT 5V TTL KENWOOD connection.
4	GND	Signal ground.
12	RELAY	Connected in parallel with the RCA phono RELAY connector.
5	ALC	Connected in parallel with the RCA phono ALC connector.
13	TX - INH	Normally to gnd. (550 ohm), stops transmission when + 12V.
6	DATA A	Bit A of Band Data (digital switch of band for YAESU).
14	DATA B	Bit B of Band Data (digital switch of band for YAESU).
7	DATA C	Bit C of Band Data (digital switch of band for YAESU).
15	DATA D	Bit D of Band Data (digital switch of band for YAESU).
8	REMOTE ON	Applying a voltage from 9 to 15 Vdc. turns the amplifier ON.

Using the above information, an appropriate cable for your transceiver(s) may be constructed, or you might wish to order a correctly made-up cable when you order your amplifier from your local dealer. The amplifier connector is included with the amplifier,



and the transceiver connector (called "Radio" in the next diagram) is usually supplied with the transceiver.


For connections to the Radio connector, refer to the transceiver operating manual.

# 12.2 SPE

In the case of SPE transceivers, it isn't necessary to make a cable because it is supplied with the transceiver.

# 12.3 ICOM

#### CAT CI-V Interface




This interface is standard for all the Icom models equipped with CAT. The cable always terminates to a 3.5 mm. mono plug.

It is possible to use a stereo plug according to the figure above.




## 12.4 KENWOOD

#### CAT RS232 Interface



The Radio connector could be DB-9 or DB-25 male connector or female connector (read the specific manual). In the manual, also verify if the RTS-CTS link is necessary.

## CAT 5V TTL Interface








The connector is described in the specific manual. Verify if the RTS-CTS link is necessary.




# **12.5 YAESU**

#### CAT RS232 Interface



The radio connector may be a DB-9 or DB-25 male connector or female connector (read the specific manual). Verify from the manual if the RTS–CTS link is necessary.


#### CAT 5V TTL Interface



The connector is described in the manual. Verify if the RTS-CTS link is necessary.




#### **BAND DATA Interface**



Without the CAT, the band is commanded by four digital signals (Band A, Band B, Band C, Band D). Refer to the specific manual.

# 12.6 TEN – TEC, FlexRadio, ELECRAFT

#### CAT RS232 Interface



**DB15 M** 

the The radio connector may be a DB-9 or DB-25 male connector or female connector (read specific manual). Verify from the manual if the RTS–CTS link is necessary.



### ALC with FLEX-RADIO.

Since this equipment has no an analog ALC input, the maximum power limits for the transceiver must be programmed in order to avoid the EXPERT's overdrive protection system intervention.

These settings have to be done while in **OPERATE Mode** according to the following.

For every ham band three settings are allowed (storage memories):

One setting for MAX mode.

One setting for MID mode.

One setting for LOW mode.

The following table shows an overall vision of these settings:


Band	160 m	80 m	40 m	30 m	20 m	17 m	15 m	12 m	10 m	6 m
MAY	Preset									
MAX	Max	Max	Max	Max	Max	Max	Max	Max	Max	Max
MID	Preset									
IVIID	Mid									
LOW	Preset									
LOW	Low	Low	Low	Low	Low	Low	Low	Low	Low	Low

The user has to set, for every band of interest, the power limit concerning the input power needed, to do that, using the keyboard, he must set a report value having the format "[PC=xxx]" (where xxx is a numerical value having a range from 000 to 100 which represents the transceiver's power output expressed in percentage).

This value will appear just over the BAND label of the Status Bar.

This value is relative to the tuned band and to the selected power mode (MAX/MID/LOW).).


In the following picture is shown (as an example) a **Power Control** in the **20 m** band and in **MAX** power mode:



Pressing the arrow keys ( $[\blacktriangleleft \blacktriangle]$   $[\blacktriangledown \blacktriangleright]$ ) this value can be decremented/incremented until it reaches the requested value; at the operation completion a time-out period (about 3 seconds) must be awaited for the "[PC=xxx]" indication to expire to permit another adjustment to be made.



In the following picture can be seen, as an example, the **Power Control** setting relative to the same band (**20 m**), but using the **LOW** mode selection instead.



Once the correct preset is adjusted, go to TX mode (RTTY, CW) to verify the output power.

ATTENTION! It is strongly recommended to start with a low preset value (e.g. 10) and progressively increase it; this is to avoid the linear overdriving.

The following empty table could be useful as a template for the FlexRadio user's Power Control pre-settings.

Band	160 m	80 m	40 m	30 m	20 m	17 m	15 m	12 m	10 m	6 m
MAX										
MID										
LOW										

## 12.7 TRANSCEIVERS OF OTHER BRANDS

A special link is not necessary as the internal amplifier frequency counter will measure the input frequency and will control the amplifier.

Note: WARNING, SPE is not responsible for any failure resulting from misuse of HW interface.




## 13. OTHER CONNECTIONS

On the connector, in addition to the CAT signals, the ALC and RELAY signals are repeated, REMOTE ON, /TX-INH, TX-INH are also available. If you use this connector to connect the ALC and RELAY lines, separate phono cables are not necessary, or it may be possible to turn the amplifier on / off by turning on / off the transceiver (REMOTE ON).


The following diagram shows how to integrate all transceiver control connections to the DB15 amplifier connector.

Check the transceiver manual for terminating that end of the cable.

# 13.1 ALC, RELAY CONNECTIONS



### 13.2 REMOTE ON LINK





## 13.3 CONNECTIONS / TX-INH, TX-INH

All modern transceivers have a delay before the transmission to allow the linear to stabilize their relays avoiding damage to them and possible effects of "Hot Switching".

The Expert 2K-FA has a settling time of only 6.5 msec. compatible with all modern transceivers (see the manual of the transceiver).

Some transceivers have an input (called TX-INHIBIT, LINEAR, MUTE, etc..) which disables the transmission.


This input can be used with transceivers that do not have such delay or, more generally, to improve the safety of switching.

The Expert 2K-FA has two outputs that can be connected to the TX-INHIBIT of the transceiver:

- a) TX-INH, usually gnd. (550 ohm), stops the transmission when @ + 12V.
- b) / TX-INH, open collector normally off, stops the transmission when it goes to ground (on)


To choose a) or b) as well as to enable the TX-INHIBIT input, refer to the manual of the transceiver.

#### TX-INH Link





### /TX-INH Link



Note: WARNING, SPE is not responsible for any failure resulting from misuse of HW interface.

### 13.4 AUX Connector

This connector provides data on the bandwidth currently used in the two INPUT, indicating which input is connected to the antenna ANT 1/2/3/4/5/6 and which is connected to the SO2R.

In this way you can know which of the two transceivers is currently connected to the output antenna set and when it is in transmission.

Pin n.	Pin name	Description
3	BIT A1	BIT A INPUT 1
5	BIT B1	BIT B INPUT 1
7	BIT C1	BIT C INPUT 1
9	BIT D1	BIT D INPUT 1
11	/ EN 1	INPUT 1 0 = not connected with ANT, 1 = connected with ANT
13	/ RLY 1	INPUT 1 0 = TX state 1 = RX state
1	GND	GND
4	BIT A2	BIT A INPUT 2
6	BIT B2	BIT B INPUT 2
8	BIT C2	BIT C INPUT 2
10	BIT D2	BIT D INPUT 2
12	/ EN 2	INPUT 2 0 = not connected with ANT, 1 = connected with ANT
14	/ RLY 2	INPUT 2 0 = TX state 1 = RX state
2	GND	GND
15	+ 12 Vdc.	OUT + 12 Vdc. 1 A max.




### Each output is open collector

Note: WARNING, SPE is not responsible for any failure resulting from misuse of HW interface.

### 13.5 PORT Connector

This connector provides:

- a) Data about the ANT port in use (each output is open collector).
- b) RS 232 port for connection to a controller of a tuneable antenna.
- c) RS 232 port for remoting use (excepted FIRST SERIES).




Pin n.	Pin name	Description
1	BIT A	BIT A antenna in use
6	BIT B	BIT B antenna in use
9	BIT C	BIT C antenna in use
5	GND	GND
2	RXD	RS232 port Tuneable Antenna
3	TXD	RS232 port Tuneable Antenna
7	TX_232 (formerly RTS)	RS232 port Remoting use
8	RX_232 (formerly CTS)	RS232 port Remoting use
4	+ 12 Vdc.	+ 12 Vdc. 1A max.

Note: In FIRST SERIES units, pins 7 and 8 were committed to RTS and CTS signals for Tuneable Antenna port.




When connecting to a control box of a tuneable antenna a suitable cable should be wired.

### SteppIR cable



#### Ultrabeam cable



Note: WARNING, these types of antennas, sometimes need several seconds to be brought to resonance..


Transmitting with high power while the antenna elements are still moving may cause damage to the antenna and the linear.

To avoid this danger you can use some circuitry that inhibits the PTT during the movement of the motors, such as the "tuning relays" available from the antenna manufacturers.

This solution is highly recommended.



### Serial connection to a standard PC RS-232 port for remoting use



Note: WARNING, SPE is not responsible for any failure resulting from misuse of HW interface.


### 14. TRANSCEIVER CONTROLLED WITH A PC

If the transceiver is controlled with a PC using the CAT utility, the link with the amplifier can be made as described in the following paragraphs.

Note: BEWARE, SPE assures only the direct connection between the Linear and the Transceiver. The use of external control software could create malfunctions that must be resolved by the provider of such software.



## 14.1 ICOM CI-V INTERFACE



The plug from the amplifier has to be connected to a CI–V port of the CT17 or similar device. The transceiver has to be connected to another CI–V port.


The following types of connections are common for Kenwood, Yaesu, TEN-TEC, FlexRadio and ELECRAFT links. DB-15 connector side of the amplifier remains the same. On the opposite side of the cable it is necessary to connect only GND and RX 232 (RX TTL) to the cable PC / Radio.

In this way, the interrogation to the transceiver is no longer made by the linear but is made by the PC, the linear analyzes just the data exchanged.


DO NOT CONNECT TX 232 (TX TTL) of the linear, the connection does not work because it would create conflict in the SW and could damage the hardware as well (see following fig.).



# 14.2 RS232 INTERFACE




## 14.3 5V TTL KENWOOD INTERFACE





### 14.4 5V TTL YAESU INTERFACE



Note: WARNING, SPE is not responsible for any failure resulting from misuse of HW interface.

# 15. USB / RS 232 PORTS USAGE

Through the USB / RS232 ports on the rear panel it is possible to interface the amplifier with a PC.

Two features are possible

- a) To remote the linear.
- b) To download the successive versions of SW.

The USB port is recommended in order to directly link the linear with a PC. In this case the SW "Term 2K USB" must be used.

The RS232 port (see "13.5 PORT Connector") is more suitable for internet use. In this case the SW "Term\_2K\_232" must be used.

These ports are in alternative so they can't be used simultaneously.

From the website <u>www.linear-amplifier.com</u> you can download these programs.

Note: In the internet use, refer to the manual of the remoting equipment.




### 15.1 REMOTE CONTROL

The software provided allows us to represent two separate windows.

The first provides an exact copy of the display, it is adjustable in size to fit any need on the control screen.

The second provides a copy of the keyboard. When not in use, it may disappear to make space on that screen.



This software allows the same operation as when standing in front of the amplifier.

### 15.2 DOWNLOAD.

The Expert 2K-FA allows you to download any new versions of SW (firmware) from the site www.linear-amplifier.com.

The software version is identified as DD\_MM\_YY\_L.pk1, where (DD\_MM\_YY) represents the date of issuance and (L) is a progressive letter.

The latest version has the most recent date and the lowest letter in the alphabet (B lower than A etc.).





To find out which version is present in the linear, press two times the [CAT] key.

"Term\_2K\_Short\_Guide" is the document which describes the installation and the main features of the SW "Term 2K" (see Appendix 1 on this manual).

### 16. MAINTENANCE

The Expert 2K-FA linear amplifier doesn't need internal maintenance because it has a cover without ventilation holes. No tube-type EHT is used so the high voltages present in tube amplifiers, which sometimes attract dirt, are not present.

The user has only to periodically check the cleaning of the air filter on the front panel.

The frequency of air filter inspection depends how dusty the amplifier location is and how much it is used. We recommend monthly cleaning of the filter.

To clean the filter

Remove the front grid.

Remove the filter and clean it with care.

Reassemble the filter and the grid after having carefully cleaned the mechanical structure that includes them.

Note: check the filter if an unexpected rise of temperature is noticed.

Note: never operate without the filter, as dust could be deposited on the surface of the

heatsink limiting its ability to cool.

Note: to allow the most efficient heat-dissipation, large copper parts have been used.



## 17. CHARACTERISTICS / SPECIFICATIONS

#### - The smallest in its class.

Built-in Power supply and Automatic Antenna Tuner..

Dimension: L 38, H 18.3, P 43 cm (14.96" W, 7.20" H,16.93" D) (connettors included).

Weight: approx: 25 Kg.(55lbs).

### - The most technologically advanced in the world

Two powerfull CPUs are used.

Over 35,000 lines of software for performance that cannot be found in any other amplifier.

### - Fully Automatic

Easy connection with all models "ICOM, YAESU, KENWOOD, TEN-TEC, FlexRadio ELECRAFT" for immediate management of the bands, tuner and antennas.

Same performance with all makes or homemade rigs.

The operator has only to move the "Frequency Tuning Knob" of the transceiver !!!

## - Wide frequency coverage

1.8 MHz to 50 MHz including WARC bands.

### Fully solid state

Up to 2 KW pep SSB, CW out; 50 MHz included.

MAX / MID (1KW) / LOW (500W) power selected according to the operator's SSB/CW power requirement, for digital modes and for linear protection (automatic).

No heating time, immediately ready!

Virtually limitless life of the amplification devices ((6 MOSFETs MRF151G).

#### - Automatic Antenna Tuner built-in

Capable of matching 3:1 SWR on HF, and 2.5:1 SWR on 6 meters.

Capable of programmable switching of 6 antennas (SO239 connectors).

Up to 3 antennas for the same band.

Management of the SteppIR / Ultrabeam antennas (tuneable).

Measure also the SWR of the antenna / cable system.

Bands, Antennas, Tuning conditions are changed in 10 msec.

Bands, Antennas and Tuning conditions are managed also in "STBY" to support the exciter only.

Max. attenuation 0.8 dB.

Bypass capability.

Remotable (option).

#### - SO2R

### - Two inputs available.

SO239 connectors.

### - High power gain (up to 14.5 dB).

In "OPERATE" the required drive power is automatically set with an ALC connection and in "STANDBY" the exciter is automatically reset to full power.

### - Very clean and low distortion output!





Spurious emissions less than -60 dB ( 50 MHz –65 dB ). 3rd order distortion (two tone test) 36 dB typ.

# - Input 50 ohm always perfectly matched

SWR less than 1.2:1.

### - Fully protected

Temperature, Over-Voltage, Over-Current, SWR, Reflected Power, Max RF Tuner Voltage, Over-Drive, Open/Short Output. The correct parameters are continuously monitored.

The same protection is realized in two different ways:

- · Via hardware circuits (HW) to assure great speed.
- · Via the software (SW), to assure great accuracy.

Thanks to the SW, <u>transmit relay changeover is carried out with zero current at the contacts.</u>

### - Full break-in operation (QSK)

### - Quiet operation.

Linear management of the speed of the cooling fans of the heatsink. In the power supply, fans speed is reduced during the reception. Since, considering the big power developed, a significant amount of heat must be removed, every precaution is used to keep the lowest possible the noise of the fans.

#### - Continuous use

"MAX" mode: SSB / CW unlimited.

Automatically switches to "MID" for a while if, in "MAX", a continuous signal (RTTY) is transmitted.

"MID" "LOW" modes, RTTY unlimited.

### - Switching power supply.

Continuous input between 190 – 255 Vac. 47-63 Hz.

PFC (Power Factor Correction).

### - The linear can be switched ON / OFF also switching the exciter ON / OFF

- Fully remotable.

### - With a large LCD display is possible to have a great deal of information

W pep out, V pa, I pa, W, Power gain, Temperatures, SWR (after and before the ATU), Input setting, CAT setting, Band and other indications including an alarms log.

### - Easy to operate

Powerful SW gives you a user-friendly unit.

### - USB / RS232 ports .

For remote control..

For new SW releases download.

### - Easy transportation

A sturdy carry-bag is supplied for "QSY, FIELD DAY, DX' PEDITIONS etc.".

#### - Certifications:

CE, FCC.

N.B. These specifications are subject to change without notice.



### 18. DIAGNOSTICS.

During normal working, the system performs a continuous monitoring of some measurements directly acquired from certain internal test-points.

When a dangerous situation is going to happen, a "serious" alarm message is raised and the amplifier is switched from **OPERATE** to **STANDBY**.

The user can either immediately restore the **Main Display Page** by pressing the [**DISPLAY**] key or wait for the visual alarm time-out expiration (about 10 seconds).

The following table shows all the system's alarm messages that are recorded in the **Alarm History** stack:

Message	Description					
SWR EXCEEDING LIMITS	Protection for SWR greater than 3:1.					
INPUT OVERDRIVING	Protection for excessive input power.					
EXCESS OVERHEATING	Protection because the internal temperature has exceeded safe limits.					
COMBINER FAULT	Protection for unbalanced combiner.					
POSSIBLE MODULE FAULT	The combiner temperature increases very fast					

While the following table shows all the dynamic warning messages that are not recorded in the **Alarm History** stack:

Message	Description
BAND NOT PERMITTED	Band not allowed or not set.
ANTENNA NOT AVAILABLE	Antenna not set.
TX ANTENNA NOT AVAILABLE	In the selected band is set only one antenna
	for reception.
STEADY OUTPUT POWER	Appears when in "MAX" is transmitted a
EXCEEDING LIMITS	digital or continuous signal, the linear
	switches automatically in "MID".
INTERNAL OVERHEATING	Appears when the internal temperature reaches
	75 $^{\circ}$ C (167 $^{\circ}$ F), the linear automatically
	switches to the power level immediately
	below.
HIGH SWR ANTENNA: TUNING	When the antenna SWR is over 3.5:1, the auto
NOT ALLOWED	tuner is not enabled to operate.
ATU BYPASS: TUNING NOT	Since the tuner is bypassed, it is not
ALLOWED	possible any matching nor automatic nor
	manual.
NO INPUT POWER: TUNING	The tuner can not work for to low input
HALTED	power.
CAN'T SWITCH-OFF: POWER	The amplifier does not turn OFF by the
HELD BY REMOTE	keyboard because it is kept ON by a remote
	device (transceiver or USB port).
COMBINER OVERHEATING	Indicates that the amplifier is going to go
	into protection for "COMBINER FAULT. "

The "COMB. BAL." on the Display is defined by two numbers:

- First shows how the temperature of the combiner circuitry increases in one minute.
- Second shows the absolute temperature of the combiner circuitry.



# **19. TABLE**

# BAND TABLE, SUB-BAND, CENTRAL FREQUENCY SUB-BAND

160 m	[ 0] 1785	[ 1] 1795	[ 2] 1805	[ 3] <b>1815</b>	[ 4] 1825	[ 5] <b>1835</b>
	[ 6] 1845	[ 7] 1855	[ 8] 1865	[ 9] <b>1875</b>	[ 10] <b>1885</b>	[ 11] <b>1895</b>
	[ 12] <b>1905</b>	[ 13] 1915	[ 14] <b>1925</b>	[ 15] <b>1935</b>	[ 16] <b>1945</b>	[ 17] <b>1955</b>
	[ 18] <b>1965</b>	[ 19] 1975	[ 20] 1985	[21] 1995	[ 22] <b>2005</b>	[23] <b>2015</b>
	[24] <b>3470</b>	[ 25] <b>3490</b>	[26] 3510	[27] 3530	[28] 3550	[29] <b>3570</b>
	[ 30] <b>3590</b>	[31] <b>3610</b>	[ 32] <b>3630</b>	[33] <b>3650</b>	[34] <b>3670</b>	[ 35] <b>3690</b>
80 m	[ 36] <b>3710</b>	[37] 3730	[ 38] <b>3750</b>	[39] 3770	[40] 3790	[41] <b>3810</b>
	[ 42] 3830	[43] 3850	[ 44] 3870	[45] 3890	[46] 3910	[47] 3930
	[ 48] 3950	[49] 3970	[50] 3990	[51] <b>4010</b>	[ 52] <b>4030</b>	
	[ 53] <b>6963</b>	[ 54] <b>6988</b>	[ 55] <b>7013</b>	[ 56] <b>7038</b>	[ 57] <b>7063</b>	[ 58] <b>7088</b>
40 m	[ 59] <b>7113</b>	[ 60] 7138	[61] <b>7163</b>	[62] 7188	[ 63] <b>7213</b>	[ 64] <b>7238</b>
	[ 65] <b>7263</b>	[ 66] 7288	[ 67] <b>7313</b>	[ 68] 7338		
30 m	[ 69] <b>10075</b>	[ 70] <b>10125</b>	[ 71] <b>10175</b>			
20 m	[ 72] <b>13975</b>	[ 73] <b>14025</b>	[ 74] <b>14075</b>	[ 75] <b>14125</b>	[ 76] <b>14175</b>	[ 77] <b>14225</b>
20111	[ 78] <b>14275</b>	[ 79] <b>14325</b>	[ 80] <b>14375</b>			
17 m	[ 81] <b>18075</b>	[ 82] <b>18125</b>	[ 83] <b>18165</b>			
15 m	[ 84] <b>20975</b>	[ 85] <b>21025</b>	[ 86] <b>21075</b>	[ 87] <b>21125</b>	[ 88] <b>21175</b>	[ 89] <b>21225</b>
10 111	[ 90] <b>21275</b>	[ 91] <b>21325</b>	[ 92] <b>21375</b>	[ 93] <b>21425</b>	[ 94] <b>21475</b>	
12 m	[ 95] <b>24891</b>	[ 96] <b>24963</b>	[ 97] <b>25038</b>			
	[ 98] <b>28050</b>	[ 99] <b>28150</b>	[100] <b>28250</b>	[101] <b>28350</b>	[102] <b>28450</b>	[103] <b>28550</b>
10 m	[104] <b>28650</b>	[105] <b>28750</b>	[106] <b>28850</b>	[107] <b>28950</b>	[108] <b>29050</b>	[109] <b>29150</b>
	[110] <b>29250</b>	[111] <b>29350</b>	[112] <b>29450</b>	[113] <b>29550</b>	[114] <b>29650</b>	[115] <b>29750</b>
6 m	[116] <b>49875</b>	[117] <b>50125</b>	[118] <b>50375</b>	[119] <b>50625</b>	[120] <b>50875</b>	[121] <b>51125</b>
	[122] <b>51375</b>	[123] <b>51625</b>	[124] <b>51875</b>	[125] <b>52125</b>	[126] <b>52375</b>	[127] <b>52625</b>
	[128] <b>52875</b>	[129] <b>53125</b>	[130] <b>53375</b>	[131] <b>53625</b>	[132] <b>53875</b>	[133] <b>54125</b>

Note: [sub-band] Central frequency KHz



# 20. Appendix 1 "Term 2K Short Guide"

#### Overview

With reference to what described at Section 15. "USB / RS 232 PORTS usage", this appendix contains the following sections:

SW installation Term\_2K\_USB.exe usage Term\_2K\_232.exe usage Firmware update


The host PC must have a correctly installed Windows XP or a further release of Microsoft's operating system (Windows Vista, Windows 7); just a minimum RAM amount and hard disk space is required.

#### 20.1 SW installation.

The installation package is contained into a compressed .**ZIP** archive named "**Term\_2K\_Package\_2\_0.zip**" which requires to be expanded in a working folder and then processed as hereafter described. This package in recorded into the equipped CD or can be downloaded from our website www.linear-amplifier.com .


Once the compressed archive **Term\_2K\_Package\_2\_0.zip** has been previously stored into a working folder. It must necessarily be expanded, that is all the files therein contained must be extracted and properly placed to the host system.

In this example the compressed archive **Term\_2K\_Package\_2\_0.zip** has been placed into a folder named **Tmp** which is contained into the local disk unit **C**: as shown in the picture below:



The next step is the archive expansion, and this can be obtained by selecting the filename and then right-clicking over it; a local menu will appear, and its **Extract All...** item will pop-up the following pre-compiled form:






The proposed destination folder is good for our purpose, so let's close this operation by using the **Extract** key marked in the picture above.


This final result will be a new uncompressed folder having the same name of the compressed one belonging to the original installation package.

Everything is contained into our working directory as shown in the picture below:





Once opened, the Term\_2K\_Package\_2\_0\Term\_2K\_Package\_2\_0 will show the following folder contents:




#### Where:

**FT\_232\_RL** is a folder containing the USB drivers and an automatic installation program, which must be run once to prepare the operating environment and that provides to sort out everything is needed (USB drivers and their support files...) on the Windows host system.

**Term\_2K\_USB.exe** is the remote control application that can be launched only after having properly installed the USB drivers.

Term\_2K\_232.exe is the remote control application especially designed to establish a connection using the special RS-232 serial port available on the EXPERT 2K-FA Second Series rear panel (that hardware is not available on First Series units).


After a left-button mouse click the following folder report will appear:







The most interesting thing for us is the **CDM20600** folder which contains, among the other things, the **CDM20600.exe** Windows application marked in the picture below:



This application has the purpose of properly installing the USB drivers. So, without making any physical link between the EXPERT 2K-FA and the PC, let's double-click, using the mouse left-button, over the "red ball" icon of CDM20600.exe application and wait for its preparatory job completed.

As soon as **CDM20600.exe** starts running, a DOS windows similar to one of the following picture will pop-up for several seconds and it will disappear after its automatic preparatory job's completion.

```
C:\Users\Eee_PC\AppData\Local\Temp\ckz_6SK4\DPInst_Monx86.exe


32-bit 0S detected
"C:\Users\Eee_PC\AppData\Local\Temp\ckz_6SK4\DPInstx86.exe"
Installing driver..

Installing driver..
```



The next step is to connect the PC and the EXPERT 2K-FA using the equipped USB cable and wait the recognition of the new USB connection.


After then a notification windows will pop-up, as shown in the picture below.



The USB port installation and setting is now complete.

Now that this fundamental step has been successfully completed, the **Term\_2K\_USB.exe** remote control application can be launched.

For this purpose a back-step to the starting uncompressed folder Term\_2K\_Package\_2\_0 must be made and a double-click with the mouse left-button on the application filename must follow it, as shown in the picture below





# 20.2 Term\_2K\_USB.exe usage

It is warmly suggested to create a link to the application on the desktop.

As a first try, let's double-click on the application's icon (the USB symbol), using the mouse left-button, just to see if everything works fine.

It is warmly suggested to create a link to the application on the desktop.


As a result the application window will show off, as in the following picture:



This is the main window of **Term\_2K\_USB.exe** application.


It is a realistic hardcopy of the **EXPERT 2K-FA** LCD display, and it is also equipped with a pop-up virtual keypad having almost the same look and feel as the real one placed on the **EXPERT 2K-FA** front panel.

To activate/deactivate this keypad the user must check/uncheck the <u>View/KeyPad</u> On/Off menu item as shown in the following screen snapshot:






<u>View</u> menu also contains five items related to the application window size presets which can be either selected by the menu itself or by their equivalent [F1 ... F5] shortcut keys. Feel free to test all the <u>View</u> menu options in order to find an optimal ad comfortable vision of the display main window.



Anyway the display window can be easily redimensioned (that is: enlarged or reduced...) by acting on the right-bottom corner of the window using the mouse as depicted in the picture above.

In case the user wants to restore the original size-preset behind any [F1...F5] key, he must select the Fx preset and, then, press the Ctrl+Fx key combination on his PC keyboard.



When **Term\_2K\_USB.exe** gets launched an automatic **Connect** command also starts and, if a USB link to the linear amplifier was already active, it should have shown a result similar to the picture sequence above.

In case this does not happen, the user can also try connecting using the <u>File/Connect</u> menu item (or using its equivalent **Ctrl+Q** shortcut key...).

The final visual result will be a "bright backlight" display and a function-keys enabling on the virtual keypad.



In case the **EXPERT 2K-FA** were already switched on after the connection established by **Term\_2K\_USB.exe**, an immediate update on the current display contents would result.

In case the **EXPERT 2K-FA** were switched off, it would be turned on by using [ON] virtual key on the application keypad.

The same way, all the other virtual keypad keys perform the same actions as their equivalent mechanical keys forming the real front panel keyboard of the **EXPERT 2K-FA**.




<u>View</u> menu is also equipped with the useful <u>Home...</u> and <u>Park...</u> items which have been especially designed to allow an automatic repositioning of the application along the PC desktop area.

In more details:

- <u>Home...</u> (Ctrl+H) item positions the display window to the upper-left corner of the desktop area and aligns the keypad to its bottom edge.
- Park... (Ctrl+N) item leaves the display window where it currently stays and just aligns the keypad to its bottom edge.

The above described operations could be helpful whenever a quick and safe repositioning of the application windows is required.



The **Basic keypad...** item in **View** menu allows to set a reduced-size keypad, having fewer keys than the complete keypad, which could be useful when no setting actions are required on the linear amplifier.




**Note**: despite the keypad types (Full and Basic) are certainly useful since they both can be directly accessed using the mouse pointer, it is helpful to know that all the operations allowed using the virtual keys can be also performed using short commands directly typed on the PC keyboard.

The following one is the "shortcut-keys" table:

Equivalent shortcut-key
from the PC keyboard
I
A
Ctrl+L
L
Ctrl+B
В
Ctrl+C
С
U
D
-
+
N
Р
Т
S
F
0

(\*) Please bear in mind that [OFF] command (either from virtual keypad or by shortcut key...) always asks for a confirmation to its amplifier shutdown operation by using the dialog form below:







**Note**: it could happen that, trying to connect the linear amplifier to the PC, some problems could arise because other peripherals sharing the same USB internal hub conflicts to it. To avoid this kind of conflict it is necessary to go to selective addressing.

### Selective addressing thru USB port.


This options has been designed to allow a selective addressing of an EXPERT linear amplifier connected to any given PC USB port.

Differently from other similar devices using the popular FT232RL USB microcontroller, where the most used way for providing selective addressing of a specific device is based upon its serial port ID parameter (e.g. COM1, COM2, etc.), or method is based upon a unique feature of the popular FTDI chip which is known as "ID String Property". This is a sequence of 8-alphanumeric characters, programmed by the FT232RL's manufacturer during the production process, which something similar to the MAC address peculiar to any PC LAN card.

From here the consideration that this unique coding parameter doesn't allow addressing ambiguity when correctly applied to FDTI chips connected to the same USB bus.


### Preliminary programming for "ID string property" within Term 2K USB.exe.

This special setting, based upon an easy "self-learning" procedure, must be performed once and with the **EXPERT 2K-FA** having previously put **OFF-LINE**. Select **File/Configure USB connection...** from the main menu as shown in the picture below:






A dialog window, as shown in the picture below, will pop up:




The user is simply required to press the <u>Acquire ID string</u> key, marked in the picture above, in order to start the <u>ID string</u> characters acquisition process across the USB data-link (guided self-learning procedure...).

In case more than one USB chip are linked to the system (directly or indirectly thru an external USB hub...) the following notification pop-up window will be shown:




In such a case the user is invited to disconnect all the devices but his EXPERT 2K-FA and retry again using the acquisition procedure above described.

In case the user detaches all the connected devices (the linear amplifier as well...) the **Term\_2K\_USB.exe** acquisition system would notify that by rising the following self-explaining pop-up message to the user:





In case of a successful acquisition process, the following pop-up notification message would be raised instead:




The picture above shows the acquisition report of a device whose **ID String Property** is **A700embB**.

As explained earlier, this parameter is unique to any specific chip, so it doesn't allow duplicates.


As soon as the notifiation message gets validated, using its OK key, the dialog form previoulsy popped will appear properly filled-in as the following picture shows:

Once the user validates the data acquisition by pressing the OK key marked in the picture above, the **Term\_2K\_USB.exe** internal database will be properly updated and,



as a confirmation of that, the application status bar will be properly updated as the following picture shows:





Once the above described steps get completed **Term\_2K\_USB,exe**, will only be able to recognize and address the **EXPERT 2K-FA** whose (unique) **ID String** matches to the one written after the **USB\_ID**: label of the picture above.

As explained earlier, this setting is permanent so, there is absolutely no need to repeat the acquisition procedure described so far any time the user wants to connect to that specific EXPERT 2K-FA unit.

Of course the acquisition procedure must be restarted again in case another EXPERT 2K-FA linear amplifier would require to be addressed; that is because another device has got, by force of circumstances, another **ID String** parameter to properly reconsider.

After having carried out all the setting and configurations steps listed in the earlier pages, everything's ready for using the FT232RL selective addressing features described so far.

All the operations tied to the **Connect** / **Disconnect** menu items are still the same as in the case of non-selective addressing procedure.


#### A last note.

If, for whatever reason, all the selective addressing capabilities are no longer needed to open a connection to an EXPERT 2K-FA thru its USB link, they can be temporarily disabled.


This operation is quite easy to perform.

After having recalled the **Configure USB connection** dialog form using its specific item contained into the <u>File</u> menu, uncheck with a mouse click the <u>Enable ID Addressing</u> option, as shown in the following picture, and validate this entry using the **OK** button.





This new setting will be notified in the application status bar with the "**Not enabled**" attribute following the **USB\_ID**: label, as shown below




**EXPERT 2K-FA** 




# 20.3 Term\_2K\_232.exe usage

To start running Term\_2K\_232.exe application it is necessary to step back into the Term\_2K\_Package\_2\_0 uncompressed folder and select the related filename as shown in the picture below:




A suggestion is to create a link to the application and to place it over the Windows desktop.

A double-click using the left-button of the mouse on the application icon should give out a result as the one shown in the following picture:






### After then select File/Virtual Com Port setting.



The above mentioned menu item makes it possible to access the following dialog box, which allows a direct setting of the desired COMx serial port for connecting the EXPERT 2K-FA.



With all the serial resources connected go to Control Panel >>> Hardware and Sound >>> Device Manager and choose a serial COM listed in the HW configuration but not used by other applications.

In case USB-to-RS232 serial converters are being used, proceed as explained and check all the COM ports polled by the system.



To check a COM port identifier related to any given adapter, disconnect it and detect which COM item disappears from the proposed list after that configuration change. In case use that COM identifier to properly set the **Virtual Com Port** dialog box shown in the picture above..


The available selection range spans thru the [COM1...COM256] set, and it can be accessed using the framed slider placed above the OK and CANCEL keys.

All the other communication parameters are set as follows:

Baud-rate: 115200 Bit per character: 8 Parity check: No

and cannot be changed since they got programmed during the "SW installation" procedure.

As mentioned above, the application usage is still the same as in the USB interface version described earlier, while the display window backlight changes to ivory-white as shown in the picture below:



Using the RS 232 port becomes a necessity when the device needs to be remotized via the Internet, since most of the committed devices currently on the market don't implement a USB port feature.

To be noted that in this peculiar version [ON] and [OFF] keys got intentionally disabled. That is because switch-on and switch-off operations on the linear amplifier are directly driven by the remotized transceiver (see Section 13.2 "REMOTE ON Connection" on the User's Manual), while for the serial interface cable wiring consult Section 13.5 "Port Connector".

**EXPERT 2K-FA** 




# 20.4 Firmware update

A very useful function of **Term\_2K\_USB.exe** is the one which enables us to update the built-in firmware of the linear amplifier.

To update the linear amplifier it is needed a suitable **.PK1** firmware file, which must be downloaded from our website <u>www.linear-amplifier.com</u> and then stored into a proper working folder.


Switch the linear on, and keep it set to STANDBY mode during the firmware update job.



Under these conditions the <u>File\Firmware update</u> menu item is active and, upon its selection it sets the **EXPERT 2K-FA** to its firmware update mode (**FIRMWARE UPDATE PROCEDURE**).

After then a dialog box will pop-up, and the user is allowed to select a proper firmware package whose data must be sent to the linear amplifier to update all its embedded functions

In the example of the picture below a firmware package file named <a href="mailto:12\_05\_12\_G.pk1">12\_05\_12\_G.pk1</a> has been selected:







After a necessary confirmation by the user for validating the procedure, the **EXPERT 2K-FA** switches its display off and the overall control for updating actions gets transferred to **Term\_2K\_USB.exe** application

The main steps of firmware update procedure are the following ones:

1. Checking and validation of updating firmware package




2. A physical data sending of the new firmware from the PC to the linear amplifier





### 3. A final validation for the completed firmware update



As a very last action after a successful firmware update, the linear amplifier performs a general auto-restart operation and, after then, a full control of the updated device is given back for both local and remote operations.

The user is then enabled to check the result of his firmware update operation directly on the LCD display (both real and virtual...) by pressing the [CAT] key twice.

This action will show

This operation will update the display report as shown below.



# 21. GENERAL RESTORE

A System General Restore can be performed by pressing [INPUT] and [OFF] keys together (for 1 second at least); this operation is only possible from the linear keyboard. The linear will switch off with a proper system message.

Upon its later switch-on all its factory defaults will be restored.



### 22. WARRANTY TERMS

SPE warrants to the original Purchaser that this product shall be free from defects of materials or workmanship.

SPE warrants for two (2) years from the date of original purchaser that SPE will provide free of charge all parts and labour necessary to correct defects in material or workmanship. The Purchaser has only to pay all the shipping expenses for warranty service work.

Customers should address requests for warranty service work to the Distributor/ Dealer where they made their purchase. As part of their reseller agreement with SPE, they are responsible for service support.

If the Distributor/Dealer has closed down, or when the Purchaser moves into another area, SPE will be directly responsible for warranty service at their factory in Rome. The shipping expenses to and from SPE will then be paid by the customer. Any repair requests to other dealers will be subject to specific direct negotiations between the customer and the dealer.

In order to not invalidate the warranty service, the original Purchaser must complete the warranty registration card, and send it to SPE no more than 30 days from the date of purchase.

Unless otherwise agreed, the products will be delivered ex-works from the factory of the seller.

The delivery, even in the event of a return for repair, is understood done with the delivery of the goods to the carrier specified by the purchaser or, failing that, to the carrier chosen by SPE.

The products will travel at the risk of the purchaser even if, at the request of the same one or for other causes, SPE should carry out transport or choose the carrier.

If the original Purchaser finds some defects after having received the equipment, he must immediately notify the Distributor/Dealer of the defects found by sending the properly filled in REPAIR FORM. Replacement of the amplifier may be done by SPE in exceptional circumstances and at SPE's complete discretion. In any case no replacement will be provided if more than the twentieth day after delivery has passed.

In case of a purchase of a used amplifier, in order to retain the warranty's validity, it is necessary to notify SPE of the following data:

- Document for the second purchase (used)
- Invoice for the original purchase
- Serial number (s/n) of equipment

Replacement of equipment in these circumstances is not an option.

In any case the warranty period shall be two (2) years from the original purchase, and not from any subsequent purchase.

Whenever the date of first sale is not well specified or is greater than one year from the date of the shipping from SPE to the Distributor/Dealer, the date of shipping from SPE to the Distributor/Dealer will be considered the start of the warranty period.





The warranty does not apply either if the certificate of the first purchase (invoice) is missing, the s/n is undecipherable/falsified or to any defect that SPE determines is due to:

- 1. Improper maintenance or repair by persons not authorised by SPE to carry out such work, including the installation of parts or accessories that do not conform to the quality and specifications of the original parts.
- 2. Misuse, abuse, neglect or improper installation, user's manual non-observance.
- 3. Carelessness, accidental or intentional damage.

SPE warrants aforesaid items only, and the Purchaser shall have no remedy and no claim for incidental or consequential damages.

It is mandatory, when sending SPE equipment to be repaired, to enclose:

- Invoice of the original purchase
- Document of the second purchase (if any)

Particular agreements between retailer and Purchaser or particular obligations imposed in other countries are matters for the local retailer and not for SPE.

In the event of dispute Rome's court of competent jurisdiction will apply.

By purchasing SPE equipment, the Purchaser declares his acceptance of the above warranty terms.



# **REPAIR FORM**

MODEL SERIAL NUMBER	DATE
CONNECTION STATE AT THE MOMENT OF THE BREAK	CDOWN
TRANSCEIVER MODEL  CAT CONNECTION   YES   NO  IF YES INDICATE THE ITEM HEADING IN THE USER'S NO  IF NO BAND DATA INTERFACE   YES ANY LINK?   YES	MANUAL
OTHER INFORMATION:	
SPACE FOR THE REPAIRER	
SI AGET ON THE NEI AINEN	
REPAIRER	DATE OF ARRIVAL
NOTES ABOUT THE AMPLIFIER WHEN YOU RECEIVED	
PARTS	S REPLACED
DATE OF TESTS	SIGNATURE OF THE REPAIRER



# **SPE** s.r.l.

Via di Monteverde, 33 00152 Rome (Italy) Tel. +390658209429 Fax. +390658209647

E-mail: <u>info@linear-amplifier.com</u>
Website: <u>http://www.linear-amplifier.com</u>